

MARATHON

WATCH, WRIST:

DIVER'S MEDIUM QUARTZ

MONTRE-BRACELET :

MONTRE DE PLONGÉE AU QUARTZ MOYENNE

INSTRUCTIONS | MODE D'EMPLOI

P/N WW194027

INSTRUCTIONS

ENGLISH



OPERATING INSTRUCTIONS: SETTING THE TIME AND DATE

If you are setting the watch for the first time, unscrew the crown, then pull it out to the first position; this is the rapid date setting position. Turn the crown clockwise to advance the date to the day before the actual date, (for example, if today is the 21st, set the date to the 20th), then proceed to set the time by pulling out the crown to the second position (most outer position). Now, turn the crown clockwise to advance the time until you see the date change to the current date, i.e. the 21st. You now know that the time is in the AM position of the 21st. Continue to advance the time to the correct hour of the day. Once done, push the crown back in and gently screw clockwise to case.

To set the time only, unscrew the crown and pull it out to the second position (most outer position). Turn the crown clockwise to advance the time. Then push the crown back in and gently screw clockwise to case.

FEATURES

This Quartz Dive Watch features hour and minute hand markers using tritium gas tube illumination. It is manufactured in accordance with ISO 6425. (Analogue, antimagnetic, corrosion resistant, dive with 60 minute unidirectional dive bezel, water resistant to 30ATM, high torque quartz movement, battery installed). This watch is equipped with a low power consumption movement with EOL (End-of-Life) display whereby the second hand advances in 4 second increments when the battery needs replacing. Other features include stop second feature, easy-set date function, sapphire crystal, maximum error rate of -0.3 seconds to +0.5 per day and shock resistant movement cage. Replacement battery is 371 button cell watch battery or equivalent.

IMPORTANT

- Crown must be screwed in completely to ensure the watch is water-resistant.
- Use only certified service centers for servicing this watch, otherwise the warranty is void.

CAUTION: Do not attempt to set date if the hands are positioned between 20:00 hours and 01:00 hours. Adjusting the date in this position will cause damage to the date mechanism and void the warranty. Use only certified service centers for servicing this watch, otherwise the warranty is void.

CLEANING:

Before cleaning your watch or exposing it to water, always make sure that the crown is screwed in completely. It is important to always rinse your watch with fresh water after it has been in salt water. To clean the watch, use a mild soap and fresh water.